

The Energy Modes are the selectable "basic settings" of your flashlight. You can choose between **Energy Saving Mode**, which optimizes burning life, and **Constant Current Mode** (constant current control) with electronically

controlled, continuous light output.



CHANGE OF ENERGY MODES (R H7R.2)

LED LENSER®

Smart Instruction Card



2 Energy Modes

- Energy Saving
- Constant Current

3 Light Programs

- Easy Low
- Easy Power
- Signal

5 Light Functions

H7.2 | H7R.2

www.ledlenser.com/SLT

FRONT SWITCH



1 x
within 1 sec.

2 x

3 x

hold
down
2 sec.

ON



OFF



PROGRAM 1 – EASY LOW

MULTI-FUNCTION SWITCH



turn



Brightness is infinitely adjustable (Power to 5 Lumen)



Flashing frequency is infinitely adjustable (Blink to Strobe)



CHANGE PROGRAM ----->



press & hold

Lamp has to be switched off!

The number of blinks shows the chosen Program.

Lamp turns on.

ON



OFF



PROGRAM 2 – EASY POWER

ON



OFF



PROGRAM 3 – SIGNAL



press &
hold
5 sec.

ON/OFF

LOCK FUNCTION

H7R.2 additional functions

2 ENERGIE MODES (see back)



REAR LIGHT



press
1x ON
2x BLINK

CHARGING STATUS DISPLAY (3 stages)

● 100-50% | ● 50-20% | ● 20-0%